



# SmartFind M6 AIS CLASS A

USER MANUAL



## General Information

### Volume 1 of 2

USER MANUAL, refer to the separate INSTALLATION MANUAL for installation and setting to work information.

#### i. Copyright

The entire contents of this instruction manual, including any future updates, revisions, and modifications, shall remain the property of Netwave Systems B.V. at all times. Unauthorized copies or reproduction of this manual, either in part or whole, in any form of print and electronic media, is prohibited. The contents herein can only be used for the intended purpose of this manual.

#### ii. Disclaimer

The information and illustrations contained in this publication are to the best of our knowledge correct at the time of going to print. We reserve the right to change specifications, equipment, installation and maintenance instructions without notice as part of our policy of continuous product development and improvement. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic or otherwise without permission in writing from Netwave Systems B.V. No liability can be accepted for any inaccuracies or omissions in the publication, although every care has been taken to make it as complete and accurate as possible. This manual is applicable for McMurdo SmartFind M6 manufactured after March 2024.

#### iii. Safety Warning



It is important to know that AIS is designed for the purpose of anti-collision and serves as a complement to navigation. It is not the absolute navigational equipment and does not replace any navigational system installed on board.

Any AIS device cannot guarantee the monitoring and receiving of signals from all vessels in the surroundings.

#### **ELECTRICAL SHOCK HAZARD**



Improper disassemble or modification could cause electrical shocks, fire, or personal injury. Contains no user-serviceable parts. Only suitably qualified personnel should attempt repair of the equipment.

### **CORRECT POWER SOURCE**



Incorrect power sources will damage the equipment and may even result in fire.

Please ensure the correct power source is provided at all times.

### **AVOID DIRECT CONTACT WITH RAIN OR SPLASHING WATER**



Electrical shock or fire could be resulted if water leaks into the equipment.

### **RADIO LICENCE**



The AIS transponder is a maritime radio transmitter. Some administrations may require that the user holds a valid radio license to cover its ownership and use.

### **RADIO FREQUENCY RADIATION HAZARD**



The AIS transponder emits low levels of radio frequency radiation. It is the operator's responsibility to ensure that no personnel come within the Maximum Permissible Exposure (MPE) radius of 1.9 m from the antenna.

### **NOTE/INFORMATION**



Throughout this manual this symbol indicates important information.

#### **iv. Product Category**

This product is categorized as “protected” in accordance with the requirements as defined in IEC 60945.

#### **v. Compass Safe Distance**

Safe distance to the transponder (and junction box) unit is:

Standard-magnetic-compass: 0.30 m

Steering-magnetic-compass: 0.30 m

#### **vi. RF Exposure Safe Distance**

The AIS transponder has been tested and meets applicable limits for radio frequency (RF) exposure. This device generates and radiates RF

electromagnetic energy and requires a Maximum Permissible Exposure (MPE) no entry zone for all personnel of 1.9 m radius around the antenna during its operation.

**vii. Hardware / Software Version**

The model name/number, hardware information, and firmware (software) version of the transponder can be identified through MKD at MENU/DIAGNOSTICS/VERSION. The software maintenance/upgrade of the transponder can be carried out on board via MicroSD card. The onboard documentation as described in the installation manual Appendix C can be used to assist reflecting software maintenance records.

**viii. Type Approval**

The AIS transponder complies with applicable international standards and is type approved in accordance with the European Marine Equipment Directive.

**ix. Declaration of Conformity**

Hereby, Netwave Systems B.V. declares that the McMurdo SmartFind M6 Class A AIS transponder is in compliance with the essential requirements and other relevant provisions of European MED Directive 2014/90/EU. A full list of applicable national type approvals and Declaration of Conformity(s) can be obtained on-line from:

[https://www.seasofsolutions.com/products/?\\_sft\\_technology=ais-electronics](https://www.seasofsolutions.com/products/?_sft_technology=ais-electronics)

**x. UK Declaration of Conformity**

McMurdo Ltd declares that this equipment is in conformity with the Merchant Shipping (Marine Equipment) Regulations 2016 as amended under Annex 1 of MSN 1874, as amended including Compliance Requirements for UK/4.32.

A copy of the Manufacturers Declaration of Conformity can be obtained online from: <https://www.seasofsolutions.com/products/>

**xi. Disposal Instruction**

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize any adverse impact of electronic equipment on the environment, both during the product lifetime and when it becomes

waste. Within the European Union this legislation is mandated by Directive 2002/96/EC, and there is similar legislation in most other continents. The directive applies to all electronic products such as IT, household appliances, portable electronics etc., and imposes requirements to collect, treat, recover and recycle each product at its end of life. Do not dispose of this device with unsorted waste. Improper disposal may be harmful to the environment and human health. Please refer to your local waste authority for information on return and collection systems in your area.

**xi. IMO Green Passport Ship Recycling Information**

Netwave Systems B.V. hereby declares potentially hazardous content in some of its electronic products. In keeping with European directive 2002/96/EC (Waste Electronic and Electrical Equipment) and the provisions of IMO Resolution A.962(23) (Guidelines On Ship Recycling), Netwave Systems B.V. strongly recommends that its products, including any battery packs, be disposed of in a considerate and legal manner.

**xii. Maintenance and contact information**

All servicing must be carried out by a Netwave Systems B.V. approved service agent. Always call your nearest agent and talk to their service department before returning equipment.

**xiii. Product Warranty**

As standard, your unit has a one year (12 months) warranty from the date of purchase shown on your invoice, however, this can be extended by a further one year by simply registering your unit on-line within 90 days of purchase at: <https://www.seasofsolutions.com/contact-us/warranty-registration/>

Warranty enquiries should be sent to:

Email: [info@seasofsolutions.com](mailto:info@seasofsolutions.com)

Telephone: +44 (0) 239262 3900

Or by mail to:

Netwave Systems B.V.

Blauw-roodlaan 100, 2718 SJ Zoetermeer, Netherlands.

or

McMurdo Ltd

Holbrook Court, E1 Cumberland Business Centre,

Northumberland Road, Southsea, Hampshire, PO5 1DS, UK

## TABLE OF CONTENTS

<b>1</b>	<b>WHAT IS AIS?</b> .....	<b>3</b>
<b>2</b>	<b>M6 OPERATION</b> .....	<b>4</b>
2.1	FRONT PANEL OVERVIEW .....	4
2.2	DISPLAY MODES .....	5
2.2.1	Radar View .....	6
2.2.2	Target Symbol Description.....	7
2.2.3	Status Bar .....	8
2.2.4	Transmission and Reception Bar.....	9
2.3	KEYBOARD.....	10
2.4	MENU TREE OVERVIEW .....	11
2.4.1	Menu Item Brief Description .....	12
2.5	MESSAGES .....	14
2.5.1	SRM Inbox.....	14
2.5.2	SRM Outbox.....	15
2.5.3	Long Range Inbox .....	17
2.5.4	Send SRM .....	18
2.6	AIS SETTINGS .....	22
2.6.1	Own Ship .....	22
2.6.2	Voyage .....	26
2.6.3	CPA/TCPA .....	29
2.6.4	Operation Mode .....	30
2.6.5	Alert Settings .....	30
2.6.6	Long Range Settings .....	31
2.6.7	Long Range Broadcast .....	31
2.6.8	VSWR Settings .....	32
2.6.9	Transceiver .....	32
2.6.10	Extended Tow Dimension .....	33
2.7	NAVIGATION OPERATION.....	34
2.7.1	Own Ship .....	34
2.7.2	Target List .....	35
2.7.3	Region List .....	38
2.7.4	GNSS Status .....	39
2.7.5	Sensor Status .....	41

2.7.6	Dangerous Target List .....	42
2.7.7	Alert List .....	43
2.7.8	Alert History .....	45
2.7.9	MOB crew list .....	46
2.8	SYSTEM CONFIGURATION .....	48
2.8.1	User Customize.....	48
2.8.2	GNSS Customize .....	49
2.8.3	I/O Port Settings .....	50
2.8.4	Password Setting .....	50
2.8.5	Firmware Upgrade.....	51
2.8.6	Ethernet Setting.....	52
2.8.7	NMEA 2000 Settings .....	54
2.8.8	Factory Reset .....	54
2.9	DIAGNOSTICS .....	55
2.9.1	Keypad Test.....	55
2.9.2	Panel Test.....	56
2.9.3	Power On/Off Log.....	56
2.9.4	Firmware Version.....	57
2.9.5	System Diagnostics .....	57
2.9.6	Debug Messages.....	58
2.9.7	Communication Test.....	58
2.9.8	Ethernet Error Logging .....	59
<b>3</b>	<b>INLAND AIS OPERATION .....</b>	<b>60</b>
3.1	INLAND MESSAGES.....	60
3.1.1	POB Outbox .....	60
3.1.2	Create POB Message .....	61
3.2	INLAND SETTINGS .....	62
3.2.1	Vessel Data Setting .....	62
3.2.2	Number of Person .....	63
3.2.3	Blue Sign Setting.....	63
3.2.4	Report Rate Setting .....	64
<b>4</b>	<b>DOCUMENT REVISIONS .....</b>	<b>65</b>

# 1 WHAT IS AIS?

The Automatic Identification System (AIS) is a Very High Frequency (VHF) radio broadcasting system that transfers packets of data over the VHF data link (VDL) and enables AIS equipped vessels and shore-based stations to exchange identification information and navigational data. Ships with AIS transponders continually transmit their ID, position, course, speed and other data to all nearby ships and shore stations. Such information can aid greatly in situational awareness and provide a means to assist in collision avoidance.

AIS equipment is standardized by ITU, IEC, IALA and IMO and is subject to approval by a certification body. The following AIS devices have been developed for variant applications.


- **AIS Class A:**  
mandated by the IMO for vessels of 300 gross tonnages and upwards engaged on international voyages, cargo ships of 500 gross tonnages and upwards, as well as passenger ships. It transmits typically on 12.5 watts output power.
- **AIS Class B:**  
provides limited functionality and is intended for non-SOLAS commercial vessels and recreational vessels. It transmits typically on 2 watts output power.
- **AIS Receiver:**  
only receives AIS signal and it does not have transmitter to send out AIS signal. Suitable for recreational vessel that does not want to send out its vessel information.
- **AIS Base Station:**  
is provided by aids-to-navigation authorities to enable the ship to shore / shore to ship transmission of information. Networked AIS Base Stations can assist in providing overall maritime domain awareness.
- **AIS AtoN (Aids to Navigation):**  
provides an opportunity to transmit position and status of buoys and lights through the same VDL, which can then show up on AIS-ready devices within the range.
- **AIS SART & AIS MOB (MSLD):**  
Search and Rescue Transmitter using AIS used to assist in determining survivor location information, typically of a life raft or a person (MOB) in the water.
- **AIS on Search and Rescue (SAR) Aircraft:**  
used on airplanes and helicopters to assist search and rescue operation.

## 2 M6 OPERATION



M6 will turn on and start operating as soon as the DC power is applied from the vessels DC switch panel.

### 2.1 Front Panel Overview



- 1 LCD Display      2 Keypad      3 Light Sensor      4 Beeper
- 5 USB              6 SD Card      7 Pilot Plug


#### Keypad Description:

Item	Icon	Name	Function(s) when pressed
1		<b>FUNCTION</b>	<ul style="list-style-type: none"> <li>● <b>Radar View:</b> Select chart orientation and type of target to show</li> <li>● <b>Target List:</b> Select sort method and what type of target to show</li> </ul>
2		<b>ESC</b>	<ul style="list-style-type: none"> <li>● <b>MENU:</b> Go back to the previous level</li> <li>● Long Press: Go to <b>Alert List</b></li> </ul>
3		<b>Voyage /SRM</b>	<ul style="list-style-type: none"> <li>● Short Press: Go to <b>Voyage</b></li> <li>● Long Press: Go to <b>Send SRM</b></li> </ul>
4		<b>MENU</b>	<ul style="list-style-type: none"> <li>● Go to <b>MENU</b></li> <li>● Long Press: Capture a screenshot and save it to the SD card</li> </ul>
5		<b>Screen brightness</b>	<ul style="list-style-type: none"> <li>● Quick switch of screen brightness (5 levels)</li> <li>● Long Press: Change screen brightness to 1<sup>st</sup> level (screen protection)</li> </ul>
6		<b>DISP</b>	<ul style="list-style-type: none"> <li>● Short Press: Display modes rotating</li> <li>● Long Press: Go to <b>User Customize</b></li> </ul>

7		Enter	<ul style="list-style-type: none"> <li>● Confirm the currently selected item</li> </ul>
8		Arrow Key	<ul style="list-style-type: none"> <li>● Move the selection cursor</li> <li>● <b>Radar View:</b> Up-Down: change scale Right-Left: select target</li> <li>● <b>Ship Detail:</b> Right-Left: change page</li> </ul>

## 2.2 Display Modes

For quick access, users can rotate display modes by simply pressing the  button.

Display Mode	Screen Shot	Purpose
<b>Radar View</b>		Displays all targets on <b>Radar View</b> (Refer to section 4.2.1 Radar View)
<b>AIS Target List</b>		Shows all received ship data (Refer to section 4.7.2 AIS Targets)
<b>Dangerous Target List</b>		Shows all dangerous AIS targets presently (Refer to section 4.7.6 Dangerous Target List)

<b>GNSS Satellite Information</b>		Shows the GNSS satellite current usage status (Refer to section 4.7.4 GNSS Status)
-----------------------------------	---	--

### 2.2.1 Radar View



Target Information

Own ship Information

Radar View displays own ship and target ships' statuses, and their correlations. It is a proportional chart scale showing the current ratio displayed. The distance between the inner and outer circles (1 grid) is the number displayed on the scale at left bottom. You can adjust the scale to display ships in different distances.

Radar View supports three ship orientation modes, North up, Head up, and Course up.

<b>N-up</b>	<b>NORTH UP</b>	The orientation is fixed and true north is always pointing up.
<b>H-up</b>	<b>HEAD UP</b>	The orientation is determined by the direction of own ship's bow.
<b>C-up</b>	<b>COURSE UP</b>	The orientation is determined by the own ship's traveling course.


## 2.2.2 Target Symbol Description

Symbols for each AIS target displayed on the **Radar View** are described as below:

<b>Own Ship</b> 	<b>Color: White</b> Own ship Icon.
<b>AIS Target</b> 	<b>Color: White</b> Ship equipped with AIS system in the surrounding sea will appear on the Radar View as an AIS target.
<b>Selected Target</b> 	<b>Color: White / Flashing Colored Frame</b> Use the arrow keys to select any target on the Radar View. After selected, press  and the detailed information on each target can be viewed.
<b>Dangerous Target</b> 	<b>Color: Red</b> When distance to a ship is smaller than CPA/TCPA, the target will be changing color to RED. Use the arrow keys to select the dangerous target and to view its detailed information.
<b>AtoN (Real)</b> 	<b>Color: Green / Plus Sign</b> The icon will be displayed if any AIS AtoN (Aids to Navigation) Real station is in the range of reception.
<b>AtoN (Virtual)</b> 	<b>Color: Green / Plus Sign and Undercut</b> The icon will be displayed if any AIS AtoN (Aids to Navigation) virtual station is in the range of reception.
<b>SAR</b> 	<b>Color: Green</b> The icon will be displayed if any SAR air plane is in the range of reception.
<b>SART</b> 	<b>Color: Green / Cross</b> The icon will be displayed if any SART message is sent out.
<b>Base Station</b> 	<b>Color: Green</b> The icon will be displayed when any AIS base station is in the reception range.

### 2.2.3 Status Bar


The **Status Bar** constantly indicates own ship position, GPS status, SRM, ALR (alert state), and Date (YYYY/MM/DD) & Time. It will indicate IL (Inland) and/or B (Blue Sign) when the system is running Inland mode.



	Inbox SRM : Unread incoming SRM
	LR Inbox : UnACK long-range interrogation
	Alert State : active – unacknowledged
	Alert State : active – silenced
	Alert State : rectified – unacknowledged
	Alert State : active – acknowledged
	Caution : active-Caution
	Indicate the system is running Inland mode
	Low RF Tx power mode
	Indicate Blue Sign device is connected
	Indicate the system is running Silent mode
	Indicate Micro SD card detected.

## 2.2.4 Transmission and Reception Bar

The **Transmission & Reception Bar**, at bottom of **Radar View**, constantly displays real time status of AIS transmission and reception, and ship orientation mode.



on or at


Item Number	Name	Function	
1	Indicators 		No transmissions & receptions: No flash
			Reception of AIS message: Flash green color
			Transmission of AIS message: Flash orange color
2	Ship Orientation Mode	N-up	North up
		C-up	Course up
		H-up	Head up
3	Compass		Indicate north direction
4	Scale		0.05 NM ~ 24 NM

## 2.3 Keyboard


Keyboard will pop up when getting into **AIS Settings, Send SRM, etc.** pages.

The following two keyboards are used when entering text and the right one is only for entering numbers.

Upon keyboard showing up on screen, user can use physical arrow keys on device front panel to traverse and select character for editing text.




-  - Use to move the caret index
-  - Confirm the entering value. (Hot key: press  for 2 seconds)
-  - Delete one character
- Esc - Leave the keyboard. (Hot key: press )
- ... - Change the keyboard character. The keyboard character will change back after entering one character.
- Lk - Lock the keyboard character



## 2.4 Menu Tree Overview

Press  to enter main MENU. There are 5 menu choices, and additional 2 menu choices for Inland mode. Each menu holds related sub-menu as depicted below.




## 2.4.1 Menu Item Brief Description

Messages	
<b>SRM Inbox</b>	Log of safety related messages (SRM) received
<b>SRM Outbox</b>	Log of safety related messages (SRM) sent
<b>LR INBOX</b>	Log of received inquiry messages from long-range interrogation
<b>Send SRM</b>	Send SRM
AIS Settings	
<b>Own Ship</b>	Your vessel setting
<b>VOYAGE</b>	Navigation setting
<b>CPA / TCPA</b>	CPA / TCPA setting
<b>Operation Mode</b>	Configure AIS mode to SOLAS or INLAND, and SART Test Mode
<b>Alert Settings</b>	Enable or disable Alert
<b>Long Range Settings</b>	Long Range settings
<b>Long Range Broadcast</b>	Long Range broadcast channel setting
<b>VSWR Settings</b>	VSWR (voltage standing wave ratio) setting
<b>Transceiver</b>	Configure silent mode and RF Tx power condition and External switch function
<b>Extended Tow Dimension</b>	Setting extended dimension values used by towing vessels. (When Navigation status is set to 12)
Navigation Operation	
<b>Own Ship</b>	Your vessel information
<b>Target List</b>	Navigation status and boat information of other AIS-equipped vessels.
<b>Region List</b>	Regional information status
<b>GNSS Status</b>	Display GNSS statuses
<b>Sensor Status</b>	Display sensor statuses
<b>Dangerous Target List</b>	Dangerous ship list
<b>Alert List</b>	Display all activated alert.
<b>Alert History</b>	Log of activated alert
System Configuration	
<b>User Customize</b>	Personalization settings
<b>GNSS Customize</b>	GNSS settings

<b>I/O Port Settings</b>	I/O port settings
<b>Password Setting</b>	Password change
<b>Firmware Upgrade</b>	Firmware upgrade
<b>Ethernet Setting</b>	Ethernet setting
<b>Factory Reset</b>	Restore all setting to default
<b>Diagnostics</b>	
<b>Keypad Test</b>	Button key test
<b>Panel Test</b>	LCD panel test
<b>Power On/Off Log</b>	Device activated log
<b>Firmware Version</b>	Firmware version
<b>System Diagnostics</b>	System diagnostics
<b>Debug Messages</b>	Debug messages
<b>Communication Test</b>	Test communication link
<b>Ethernet Error Logging</b>	Display Ethernet Error Logging
<b>Inland Messages</b>	
<b>POB Outbox</b>	Log of Person On Board message (RFM55 or IFM16) sent
<b>Create POB Message</b>	Create Person On Board message (RFM55 or IFM16)
<b>Inland Settings</b>	
<b>Vessel Data Setting</b>	Configure vessel data
<b>Number of Person</b>	Set number of persons
<b>Blue Sign Setting</b>	Set blue sign settings
<b>Report Rate Setting</b>	Set report rate settings


## 2.5 Messages


When a SRM (Safety Related Messages) from other AIS equipped vessels is received, the status bar will display , the new message icon.




### 2.5.1 SRM Inbox

You can read received SRM under Inbox. Use   to traverse the message list and highlight your choice. Read the message content by pressing .





When pressing , system will show 3 options. You can choose to **reply** the highlighted message or **delete** it or **delete all** messages in SRM Inbox. Press  to confirm your choice.



## 2.5.2 SRM Outbox

You can read all sent SRM under Outbox. Use   to traverse the message list and highlight your choice. Read the message content by pressing . In Tx column, you can see 3 different icons.  means the device is still sending the message. After sending the message, Tx column will show  that means the

message has been successfully sent, if failure it will show 


25°03.5555'N		2023/05/04		
121°38.0733'E		14:22:19		
<b>SRM Outbox</b>				
MMSI	Message	Date/Time	Tx	1/3
751000000	TEST MESSAGE	05/4 09:59	<input type="checkbox"/>	
751000001	TEST MESSAGE	05/4 09:58	<input checked="" type="checkbox"/>	
751000002	TEST MESSAGE	05/4 09:57		

25°03.5555'N		2023/05/04	
121°38.0733'E		14:22:55	
<b>Messages</b>			
MMSI	22222222	Destination MMSI	751000000
Date/Time	05/4 09:59	ACK	NO
Message Type	default		
Message Content	TEST MESSAGE		

When pressing , system will show 2 options. You can choose to **delete** it or **delete all** messages in SRM Outbox. Press  to confirm your choice.

### 2.5.3 Long Range Inbox


When the transponder is connected to a long range communication system via the long range communication port then long range interrogations may be received. These are requests for information from a distant base station beyond normal AIS operation range. LONG RANGE Inbox holds all received Long Range Interrogation messages.



25°03.5555'N 121°38.0733'E 2023/05/04 14:49:26

**LR Inbox**

MMSI	Name	Date/Time	ACK	1/2
750000000	LR-Name-0	05/04 09:59	<input type="checkbox"/>	
750000001	LR-Name-1	05/04 09:58	<input checked="" type="checkbox"/>	



25°03.5555'N 121°38.0733'E 2023/05/04 15:01:40

**Messages**


Request MMSI	750000000	ACK	NO
Request Name	LR-NAME-0		
Date/Time	05/04 09:59		
Interrogation Area			
Latitude(NE)	20.383333		
Longitude(NE)	123.96667		
Latitude(SW)	19.583334		
Longitude(SW)	123.04995		

Use   to traverse the message list and highlight your choice. Read the message content by pressing .


When pressing , system will ask whether the highlighted message should be acknowledged. Press  to confirm your choice.

## 2.5.4 Send SRM

This submenu allows the users to compose a Safety Related Message (SRM). Maximum length for the message is 85 characters. **Message Type** gives you the option to send the broadcast message or the addressed message. If the user chooses to send the addressed message, the system will show **MMSI** below the **Message Type**.



The screenshot shows the 'Send SRM' interface. At the top, the coordinates '25° 03.5555'N' and '121° 38.0733'E' are displayed on the left, and the date '2022/03/24' and time '14:48:09' are on the right. The title 'Send SRM' is in orange. Below it, the 'Message Type' section has a dropdown menu with 'Broadcast SRM' selected. The 'Channel' is set to 'No Preference'. The 'Message Content' field is a large text area with the placeholder 'Enter text here'. A 'Send' button is at the bottom.



The screenshot shows the 'Send SRM' interface with 'Addressed SRM' selected in the 'Message Type' dropdown. The 'Channel' is 'No Preference'. The 'Message Content' field is a large text area with the placeholder 'Enter text here'. A 'Send' button is at the bottom. The 'Addressed SRM' option is highlighted with a yellow border, and a 'Broadcast SRM' option is visible below it.

25°03.5555'N 121°38.0733'E 2022/03/24 14:49:43

### Send SRM

Message Type **Addressed SRM**

MMSI **000000000**

Channel No Preference

Message Content

Send

25°03.5555'N 121°38.0733'E 2022/03/24 14:50:20

### Send SRM

Message Type Addressed SRM

MMSI **000000000**

Channel No Preference

Message Content


Send

**MMSI**

Character left : 9

1	2	3	ⓧ
4	5	6	ESC
7	8	9	
0	←	→	→

After entering the MMSI number, choose the **Channel**. It gives you the option to send message through channel A, B or Both A & B. By No Preference, which is the default option, the system will select the channel automatically. Then, compose the message.




25° 03.5555'N  
121° 38.0733'E  
2022/03/24  
14:51:19

### Send SRM

Message Type Addressed SRM  
MMSI 222222221  
Channel No Preference  
Message Content Enter text here

- No Preference
- Only Channel A
- Only Channel B
- Both Channel A & B

Send



25° 03.5555'N  
121° 38.0733'E  
2021/11/17  
15:07:58

### Send Message Content

Character left : 85

Mes

MM 1 2 3 4 5 6 7 8 9 0 + [X]


Cha Q W E R T Y U I O P \_ [←]

Mes A S D F G H J K L : [ ] [→]


Z X C V B N M , . / " \

Lk ... ESC [→]

To send the message, press the send button on the bottom of the view and the system will ask whether to send the message. Select **YES** to send and return to Messages submenu, **NO** to cancel and stay at this view.




To leave this page, press  and the system will ask whether to leave this view. Select YES to leave, NO to stay at this view. For simple use, press  two times and the system will return to the Messages submenu.



## 2.6 AIS Settings

This menu list provides access to settings that are required during installation of the transponder. There are a total of 9 submenus.



### 2.6.1 Own Ship

**Note:** Own ship settings are operator password protected, changes can only be saved when the operator password is entered. For password details, see section 2.12 of the M6 installation manual.

The following information about the vessel should be correctly set up by installation technician prior to operation.

- Ships MMSI number
- Ship Name – limited to 20 characters
- Ship IMO number
- Call Sign – vessel radio call sign (limited to 7 characters)
- Position of internal GPS antenna – giving the location of the GNSS antenna connected to the AIS transceiver (integrated internal GPS receiver)
- Position of external GPS antenna – giving the location of the GNSS antenna connected to any external position source connected to the AIS transceiver
- Length and Beam – measured length and width of the ship (inland mode only)

25°03.5555'N 121°38.0733'E 2023/05/04 16:18:01

**Own Ship** SAVE

MMSI  Ship Name --  
 IMO  Call Sign --

Internal Antenna Position (m)  
 A -- B -- C -- D --  
 External Antenna Position (m)  
 A -- B -- C -- D --

25°03.5555'N  121°38.0733'E 2023/05/04 16:39:23

**Own Ship(Inland)** SAVE

MMSI  Ship Name --  
 IMO  Call Sign --

Length and Beam (m)  
 LS -- BS --

Internal Antenna Position (m)  
 A -- B -- C -- D --  
 External Antenna Position (m)  
 A -- B -- C -- D --




25°03.5555'N 121°38.0733'E 2023/05/04 16:40:49


**Own Ship** MMSI

MMSI  Ship Name Character left : 9  
 IMO  Call Sign

Internal Antenna Position (m)  
 A -- B -- C -- D --  
 External Antenna Position (m)  
 A -- B -- C -- D --

1	2	3	⌫
4	5	6	ESC
7	8	9	
0	←	→	→





## 2.6.2 Voyage

In this submenu the following navigational information can be configured:

- Destination - Ship's next destination port (limited to 20 characters).
- ETA Date - Estimated date of arrival at destination (using UTC time)
- ETA Time - Estimated time of arrival at destination (using UTC time)
- Ship Type - use direction keys to select the type of vessel from the list
- Ship Cargo - use direction keys to select the type of vessel from the list
- Navigation status – use direction keys to select the suitable status from the list
- Person – the number of person on board

25°03.5555'N  
121°38.0733'E

2023/05/05  
09:33:34

Voyage SAVE

Destination	--	
ETA Date	mm/dd	Set1
ETA Time	hh:mm	Set2
Ship Type	30 - Vessel Fishing	Set3
Ship Cargo	0 - All ships of this type	Set4
Navigation Status	15 - Undefined	Set5
Draught(m)	25.5	
Person	8191	

**Notice:** if Ship Type is Tanker, by regulation, whenever the ship navigation status is “Moored”, the transponder’s transmission power is automatically changed to 1W for safety measures.

At the right side of the view, you can see a block (Set1 ~ Set5) when pressing  , you can input the setting name and then the system will save the current voyage setting to this Set. Next time, if you want to use the same setting, just select the Set, you saved, and press  . The system will apply the setting to the current voyage value.

25°03.5555'N 2023/05/05  
121°38.0733'E 09:46:50

Voyage SAVE

Destination	--
ETA Date	mm/dd
ETA Time	hh:mm
Ship Type	30 - Vessel Fishing
Ship Cargo	0 - All ships of this type
Navigation Status	15 - Undefined
Draught(m)	25.5
Person	8191

Set1  
 Set2  
 Set3  
 Set4  
 Set5

25°03.5555'N 2023/05/05  
121°38.0733'E 09:54:05

Voy **Input the setting name** Character left : 7

Des TPE



ETA	1	2	3	4	5	6	7	8	9	0	+	ⓧ
ETA												
Ship	Q	W	E	R	T	Y	U	I	O	P	_	←
Ship												
Nav	A	S	D	F	G	H	J	K	L	:	[	→
Dra												
Pers	Z	X	C	V	B	N	M	,	.	/	"	\
	Lk									...	ESC	→

25°03.5555'N 2023/05/05  
121°38.0733'E 09:55:37

Voyage SAVE

Destination	--
ETA Date	mm/dd
ETA Time	hh:mm
Ship Type	30 - Vessel Fishing
Ship Cargo	0 - All ships of this type
Navigation Status	15 - Undefined
Draught(m)	25.5
Person	8191


TPE  
 Set2  
 Set3  
 Set4  
 Set5



### 2.6.3 CPA/TCPA

In this submenu the closest point of approach (CPA) and time to CPA (TCPA) can be set. The vessels with insufficient CPA and TCPA will be displayed in the dangerous list and radar view with red color.


- CPA - in nautical miles
- TCPA - in minutes



To save the setting, select the SAVE button in the view and press . The system will ask whether the changes should be saved. Select YES to save or NO to discard and return to AIS settings submenu.


## 2.6.4 Operation Mode

You can configure the transponder to operate in SOLAS or INLAND mode. Each mode has some specific submenu and menu options. Displaying the SART Test on the M6 screen can be enabled or disabled by configuration setting (ON/OFF) as well.



## 2.6.5 Alert Settings


This submenu can be used to enable or disable ALF sentence. For instance, if an ALF sentence is not enabled, the corresponding alarm would not activate.



## 2.6.6 Long Range Settings

This section is password protected, value changes can only be saved using the operator password. This menu provides user choices to auto-response remote interrogation and settings of the response information.


You can set **Mode** to either Auto or Manual. The setting for the rest of information is either Provide or Not Provide.



25° 03.5555'N	2023/05/05
121° 38.07 33'E	11:53:42
<b>Long Range Settings</b> <span>SAVE</span>	
Mode	Auto
Name, Call Sign, IMO	Provide
Length, Breadth, Type	Provide
Date, Time	Provide
Ship Cargo	Provide
ETA	Provide
Draught(m)	Provide
Position	Provide
COG	Provide

## 2.6.7 Long Range Broadcast


This section is password protected, value changes can only be saved using the operator password. Class A transmits Message 27 every 3 minutes through the channels alternately. Provided here are the options to change the transmitting channel (default 75 or 76) for Message 27.



25° 03.5555'N	2023/05/08
121° 38.07 33'E	09:50:52
<b>Long Range Broadcast</b> <span>SAVE</span>	
Long Range AIS Broadcast Channel 1	75
Long Range AIS Broadcast Channel 2	76


## 2.6.8 VSWR Settings

The VSWR setting function allows the fine-adjustment of VSWR threshold according to the cable length and VHF antenna characteristics.



## 2.6.9 Transceiver

This section is password protected value changes can only be saved using the operator password. The submenu allows the users to switch on or off the transmission and enable to switch the transmission power between 12.5 W, as “normal”, and 1 W. The External Switch (SOLAS Mode Only) allows the user to set “No Function” and “Low TX Power Mode” function for “BLUE\_SIGN” connector on Junction Box.



## 2.6.10 Extended Tow Dimension


This option provides users to setting extended dimension values used by towing vessels.

Under the following two conditions, this option will appear in the Menu.

1. AIS operate mode is INLAND mode or
2. in SOLAS mode, and Navigational Status is 12 = power-driven vessel pushing ahead or towing alongside.




## 2.7 Navigation Operation



### 2.7.1 Own Ship

This option displays the full information on your ship, including both dynamic and static data. Use direction keys to change between dynamic and static information.

- **Static data and Dynamic data**



25°03.5555'N		2023/05/08	
121°38.0733'E		11:13:42	
<b>Own Ship</b>			
Call Sign	--	EPFD	Undefined <span style="float: right;">2/2</span>
IMO	0	RAIM	--
Ship Type	0		
Ship Cargo	0 - All ships of this type		
Destination	--		
ETA	--	Draught(m)	0.0
Dimension	--	Person	0
Manoeuvre indicator	Not available	DTE	Not available

- **Inland Vessel Information**

The following information is only available under inland mode.

25°03.5555'N		2023/05/08	
121°38.0733'E		11:15:43	
<b>Own Ship</b>			
ENI	--	Quality of Speed	Low <span style="float: right;">3/3</span>
Ship Length(m)	0.0	Quality of Course	Low
Ship Beam(m)	0.0	Quality of Heading	Low
ERI Ship Type	--		
Blue cones	0	Crew members	0
Draught(m)	0.0	Passengers	0
Load Status	Loaded	Shipboard personnel	0
Blue Sign	Disabled	Persons on Board	0

## 2.7.2 Target List

This option displays all received AIS information of other vessels including dynamic and static information. Use direction keys to select AIS target and then press  to go through dynamic and static information of the selected vessel. There are two pages of ship details for SOLAS mode and another one page for Inland mode.

25°03.5555'N 2023/05/08  
121°38.0733'E 11:26:50

### Target List

	Name/MMSI	AGE	BRG	RNG	1/12
	BARLIAN T1201	23s	125	4.31	
	TB SOL 1010	12s	325	5.57	
	440982000	9s	27	12.52	
	477770700	3m10s	164	1.84	
	CRYSTAL RIVER	1s	59	2.50	
	STAR ADMIRAL	10m23s	210	7.85	
	525009342	33s	188	2.50	
	538008570	2m13s	19	3.56	
	563051600	50s	12	9.85	

25°03.5555'N 2023/05/08  
121°38.0733'E 11:28:19


### Target Detail

Ship Name	--		
MMSI	--	SOG	--
Latitude	--	COG	--
Longitude	--	ROT	--
Navigation Status	0 - Under way using engine		
Position Accuracy	Low		
Position Quality	--	BRG	--
CPA (NM)	--	RNG	--
	TCPA(min)	--	

1/2

Use direction keys to continue reading the dynamic and static information of the selected vessel.


Additional inland information is available under inland mode.



- **Sorting vessels**

In the list, press Fn will open the pop-up window and user can sort the list according to vessels' MMSI, direction (BRG), or distance (RNG). Also user can choose what kinds of ship type whether should be displayed in the target list.


In the screenshot of the Target List, one subtitle has different color between others indicates the current sorting method.




## 2.7.3 Region List

The region list displays all saved region areas. Use direction keys to traverse the list.

Press  enables you to read the highlighted region information.





In Use	LAT(NE)	LON(NE)	LAT(SW)	1/1
<input type="checkbox"/>	23° 30.0000' N	121° 30.0000' E	19° 30.0000' N	122° 30.0000' E



Latitude(NE)	20° 30.0000' N	Power	High
Longitude(NE)	123° 30.0000' E	Source	ACA sentence
Latitude(SW)	19° 30.0000' N	TX/RX Mode	TxA/TxB/RxA/RxB
Longitude(SW)	122° 30.0000' E		
Only Channel A	2022	Bandwidth	0
Only Channel B	2061	Bandwidth	0
Transition Zone(NM)	5		

- **Editing or Adding region content**

You can add or modify the region area setting by pressing  at the region list page. Use direction keys to select the field to edit, then press  to enter the value.



## 2.7.4 GNSS Status

In this submenu the following GNSS information is displayed:

- GNSS Status - show device's GNSS data
- GNSS Constellation - GNSS source location distribution
- Ship Location -
- Satellite Signal to Noise Ratio - GNSS source signal magnitude

25° 03.5555'N 121° 38.0733'E 2023/05/08 15:41:07


### GNSS Status

Antenna Altitude <b>0.00</b>	SOG --	COG --	   
PDOP --	HDOP --	VDOP --	
No. SV/SU <b>0 / 0</b>	UTC Time --	Local Time --	

25° 03.5555'N 121° 38.0733'E 2023/05/08 15:41:45

### GNSS Constellation

In View: 0 In Use: 0



SNR scale: 00 to 50


  
  
  


25° 03.5555'N 121° 38.0733'E 2023/05/08 15:42:09


### Ship Location



## 2.7.5 Sensor Status



Display sensor statuses:

SENSOR	STATUS
<b>Position Status</b>	External position source other than GNSS Internal GNSS in use External GNSS in use Internal DGNS in use (corrected; beacon) Internal DGNS in use (corrected; Message 17) External DGNS in use
<b>Position Quality</b>	No position Manual position Dead reckoning position valid position with no time stamp

	Position > 10m Position with RAIM > 10 m Position <= 10 m Position with RAIM <= 10 m Outdated position > 200 m
<b>UTC Status</b>	Valid / Invalid (Note 1)
<b>COG Status</b>	Internal COG / External COG / Invalid
<b>SOG Status</b>	Internal SOG / External SOG / Invalid
<b>Heading Status</b>	Valid / Invalid
<b>ROT Status</b>	Valid / Other ROT / Invalid
Note 1: When AIS not connected with internal GPS, UTC got lost and time unsynchronized, then the M6 will continue operation using indirect or semaphore synchronization.	

### 2.7.6 Dangerous Target List

With the setup of closest point of approach (CPA) and time to CPA (TCPA), this submenu provides an efficient way to monitor vessels with insufficient CPA and TCPA. The dangerous targets can also be observed on radar view (with red color).

Use direction keys to traverse the list and press  to read information of the selected vessel.




## 2.7.7 Alert List

M6 features SART/MOB alarm that can appear any time during operation. When SART/MOB message is received, the  or  icon will appear in the status bar with beeping sounds twice from the buzzer.

There are 2 ways to access the Alert List: either through Main Menu/Navigation Operation/Alert List or with the hot key by holding  for 3 seconds and the system will enter the Alert List screen. Another hot key in Alert List, by pressing  you can select the alert between the first and the last.

The list shows all current AIS alerts and their status. Use direction keys to navigate the list. You can acknowledge (ACK) the alert message by pressing . The system will ask for confirmation if the chosen alert should be acknowledged. If the alert has not yet acknowledged, an indication icon  will appear in the status bar till all acknowledged are made.

The transponder performs a function self-check continuously. If a self-check fails an alarm will occur. The Appendix shows all possible alarm scenarios.



The screenshot displays the Alert List interface. At the top, it shows coordinates (25°03.5555'N, 121°38.0733'E) and the date/time (2023/05/08, 16:30:49). The title 'Alert List' is in orange. Below is a table with columns: Alert Identifier, Alert Text, Priority, BIIT ID, and State. One alert is listed with ID 3108, text 'Locating device', priority 'W', and BIIT ID '14'. At the bottom right, it shows '1/1'. Below the table is a section for 'Additional Information' with a text box containing 'Check AIS targets'.

Alert Identifier	Alert Text	Priority	BIIT ID	State
3108	Locating device	W	14	

Additional Information 1/1

Check AIS targets

**Table – BAM alert instance**

Alert ID	Alert text	Additional information	Prio	Cat	Escal	BIIT ID
3108	Locating device	Check AIS targets	W	B	W	14
3062	General fault	Check AIS equipment	W	B	W	6
3008	Transceiver fail	Not transmitting, check AIS	W	B	W	1
		Not receiving, check AIS	W	B	W	3、4
3015	Lost position	Own ship position not transmitted	W	B	W	26
3116	Impaired radio	Reduced coverage (antenna VSWR)	C	B		2
		Ch1 inoperative, check AIS	C	B		3
		Ch2 inoperative, check AIS	C	B		4
		DSC inoperative	C	B		5
3113	Sync in fallback	Check AIS for UTC time synchronisation	C	B		7
3003	Lost ext EPFS	Check external position sensor	C	B		25
3119	Missing COG	Not transmitting COG	C	B		30
	Missing SOG	Not transmitting SOG	C	B		29
	Missing Heading	Not transmitting Heading	C	B		32
	Missing ROT	Not transmitting Rate of Turn	C	B		35
3013	Doubtful GNSS	Int/Ext GNSS position mismatch	C	B		9
	Doubtful heading	Difference with COG exceeds limit	C	B		11
3019	Wrong NavStatus	Check NavStatus setting	C	B		10
3009	Lost MKD	Cannot display safety related messages	C	B		8

Note 1, Alert priority (Prio): W (Warning) \ C (Caution)  
 Note 2, BIIT ID 1 is generated if there is a malfunction in the transmitter hardware or the MMSI is set to "0".

**Table** – Alert state and audible annunciation for warnings


Alert state	Visual presentation	Audible annunciation
V: active – unacknowledged		2 short audible signals and repeated as a warning after 3 minutes
S: active – silenced		None
A: active – acknowledged		None
U: rectified – unacknowledged		None

**Table** – Alert state and audible annunciation for cautions

Alert state	Visual presentation	Audible annunciation
A: active		None


### 2.7.8 Alert History

This submenu lists all recorded alarms and time of occurrence.



## 2.7.9 MOB crew list


This page explains how to assign a friendly crew name to an individual AIS MOB Marine Survivor location device (MSLD) or AIS SART. The pre-entered name can then be displayed upon receiving an AIS MOB message alert from the crew members allocated MMSI identity. An SD Card should be inserted under the M6 front facing cover flap, used to store the crew MOB crew list information. Up to 100 sets of MMSI with crew member name can be stored.



Pressing **Fn** will display the following three sub-menus.

- Read From SD Card: Read MMSI and Names from MobList.csv list saved on the SD card.
- Save To SD Card: Save MMSI and Names to MobList.csv on the SD card.

- Clear MOB List: Delete all MMSI and Names.



It might be more convenient to edit a large crew name list on a computer screen. Use a text editor program to access the SD card from a computer and edit and re-save the MOBList.CSV file.

The format of the MOBList.CSV file is as shown here. The first-row column A must contain “MMSI” then in column B “Name”. The crew list then starting from the second row, input the desired MMSI and Names. Be careful to keep the same file name when re-saving the list.


	A	B
1	MMSI	Name
2	970050001	JIM
3	970050002	PETTER
4	970050003	SAL
5	970050004	MAGGIE
6	970050005	WINNE
7	970050006	GEORGIA

## 2.8 System Configuration

System configuration provides access to user configurable preferences for M6. All user settings are stored within the transponder and will be maintained if the power supply is switched off.

After the setting is done, press SAVE button in the view and the system will ask whether the changes should be saved.


Select YES to save or NO to discard and return to System Configuration submenu.



### 2.8.1 User Customize


Customize provides personalization settings:

- Language - select the user interface language from the available language options
- Dimmer - brightness setting from 0 (low) to 10 (high)
- Dimmer Mode – set the Dimmer Mode to Auto or Manual
- Key Beep - turn on or off the key beep
- Time Zone - set the time zone



### 2.8.2 GNSS Customize

This submenu allows the user to change the supplied voltage of the GNSS antenna between 3.3 V or 5 V and select up to 3 of the 4 GNSS systems supported at any one time. It also allows to switch the operating altitude.



### 2.8.3 I/O Port Settings

This option provides an overview of baud rates and checksum on all ports.



The screenshot shows the 'I/O Port Settings' menu with a 'SAVE' button in the top right. The menu displays a table with three columns: Port, Baud Rate, and Checksum. The 'Baud Rate' column for the first row is highlighted. The table lists the following ports and settings:

Port	Baud Rate	Checksum
PILOT (front)	38400	Required
PILOT (rear)	38400	Required
DISP	38400	Required
Long Range(LR)	38400	Required
DGNSS	38400	Required
Sensor 1	4800	Required
Sensor 2	4800	Required
Sensor 3	4800	Required
USB		Required

### 2.8.4 Password Setting


This submenu enables change of the default operator password. Certain important settings stored within the transponder can only be changed using the operator password.

The Password is required for the access of the following chapters:

- Own ship - contains information about MMSI, vessel name, IMO, call sign and dimension.
- Long Range Settings -
- Long Range Broadcast -
- Transceiver - enables the option to activate/deactivate AIS transmission
- I/O Port Settings - about baud rate configuration of sensors


**Default password:** please refer to section 2.12 in INSTALLATION Manual

Use direction keys to select **Old Password**, **New Password** and then press  to enter value. To save the settings, press SAVE button in the view and the system will ask whether the changes should be saved. Select YES to save or NO to discard and return to System Configuration submenu.



## 2.8.5 Firmware Upgrade

This option is used when upgrading the transponder firmware version from the SD card.



## 2.8.6 Ethernet Setting


The default IP address and Mask is 192.168.0.100/24. Input groups NAVD, TGTD and SATD are always enabled.

In this submenu the following Ethernet setting can be configured:

- IP address and network mask of AIS transceiver
  - Valid IP address ranges are shown as below:  
10.0.0.0 ~ 10.255.255.255 (10/8 prefix)  
172.16.0.0 ~ 172.31.255.255 (172.16/12 prefix)  
192.168.0.0 ~ 192.168.255.255 (192.168/16 prefix)
- SFI of AIS transceiver
  - SFI Range for AIS is AI0000 ~ AI9999. If SFI is AI9999 (default), M6 will not send data to Ethernet.
- Additional input multicast group
  - This setting is used for additional input groups.
- Transmission group
- SFI for Primary position sensor
- SFI for Secondary position sensor
- SFI for Primary SOG/COG sensor
- SFI for Secondary SOG/COG sensor
- SFI for Primary heading sensor
- SFI for Secondary heading sensor
- SFI for Primary ROT sensor
- SFI for Secondary ROT sensor
- SFI for Primary AIS Control
- SFI for Secondary AIS Control
- SFI for Primary alert command source
- SFI for Secondary alert command source

Table – Input transmission groups with applicable sentences

Tx group	Multicast address	Port	Typical talker ID	Typical sentences	Message type
NAVD	239.192.0.4	60004	GA, GP, GN, LC, IN, HE, TI	DTM, GBS, GNS, RMC, VBW, VTG, GGA, GLL HDT, THS, ROT	SBM
NAVD	239.192.0.4	60004	EC, EI, IN	ABM, ACA, AIR, BBM, SSD, VSD	CRP
TGTD	239.192.0.2	60002	RA	ABM, ACA, AIR, BBM, SSD, VSD	CRP
SATD	239.192.0.3	60003	HE	HDT, THS	SBM
PROP	239.192.0.8	60008	Proprietary	PAMC	SBM



## 2.8.7 NMEA 2000 Settings

This page provides users with the option to enable or disable NMEA 2000, as well as configure System Instance and Device Instance settings.

25°03.5555'N  
121°38.0733'E

2023/11/16  
09:58:19

### NMEA2000 Settings

SAVE

NMEA2000	Enabled
System Instance	0
Device Instance	0

## 2.8.8 Factory Reset

This page allows the user to restore the default factory settings. It will restore the system preference settings and AIS settings.

25°03.5555'N  
121°38.0733'E

2023/05/09  
14:32:52


### Factory Reset

Factory reset will restore all settings to default.

Restore


## 2.9 Diagnostics

This submenu provides users to check system statuses. There are a total of 7 check options.



### 2.9.1 Keypad Test


This option provides keyboard testing. Pressing button during testing, a corresponding button on the screen will response. After all buttons are tested, a message will indicate. Press OK to exit. To quit test without completing, wait for 30 seconds and the system will return to the Diagnostics submenu.



## 2.9.2 Panel Test


In the submenu users can test the brightness of the screen.

Use   to switch the white cube between different sizes. Use   to test different stages of brightness. To exit the function, press .




## 2.9.3 Power On/Off Log

This option provides activation and silent mode history. An event of less than 15 minutes duration will not be recorded in the history.




## 2.9.4 Firmware Version

Provide model name, transponder firmware, display firmware, etc.




## 2.9.5 System Diagnostics

This option provides users to simply check the transponder condition. Press  the system will reset the time and count value.



## 2.9.6 Debug Messages

This page displays NMEA 0183 sentences output by AIS.



## 2.9.7 Communication Test

Communication between M6 and other Class A device can be tested. The procedure starts by transmitting Message 10 to an addressed Class A MMSI. The addressed MMSI, once received Message 10, will return Message 11. The test is then complete when the transponder successfully receives the Message 11.




Press **Fn** to start the communication test. The system will show Target List that only has targets with Class A type. Use direction keys to select a target and then press **↑** to start the transmission of Message 10.

## 2.9.8 Ethernet Error Logging


This option provides users to check the counts of errors detected in processing datagrams containing IEC 61162-1 sentences from Ethernet.

- TAG checksum error;
- TAG syntax error (line length, use of delimiters, invalid characters);
- TAG framing error (incorrect start or termination of TAG block);



### 3 INLAND AIS OPERATION

#### 3.1 Inland Messages




##### 3.1.1 POB Outbox

The submenu displays log of sent Number of person on board (RFM55/IFM16) messages. The SOLAS Mode sends the total number of persons on board as a binary message with international IFM16.

The Inland Mode sends a message with number of crew, personnel and passengers as a binary message with inland branch RFM55 or IFM16.

Use direction keys to select a message and press  to display message content.




### 3.1.2 Create POB Message

In this submenu users can compose number of person on board (RFM55/IFM16) messages. Number of person onboard can be configured in Inland Settings. When “Broadcast SRM” is selected, just omit the Destination MMSI. The **Data Type** provides the option either to send the data in RFM55 or IFM16. Channel gives you the option to send the message through channel A, B, A&B, or No Preference. By No Preference, which is the default option, the system will select the channel automatically.

The screenshot displays the 'Create POB Message' interface. At the top, it shows the current location coordinates (25°03.5555'N, 121°38.0733'E) and a call sign 'IL'. The date and time are 2023/05/09 at 16:14:38. The main title is 'Create POB Message' with a 'Send' button. Below this, there are four fields: 'Destination MMSI' (000000000), 'Message Type' (Broadcast SRM), 'Data Type' (RFM55), and 'Channel' (No Preference). The 'Broadcast SRM' field is highlighted. Underneath, there are two sections: 'Inland Persons Information' and 'SOLAS Persons Information'. The 'Inland Persons Information' section shows 'Crew members' and 'Passengers' both set to 0, and 'Shipboard personnel' set to 0. The 'SOLAS Persons Information' section shows 'Number of Person' set to 0.

Field	Value
Destination MMSI	000000000
Message Type	Broadcast SRM
Data Type	RFM55
Channel	No Preference
Inland Persons Information	
Crew members	0
Passengers	0
Shipboard personnel	0
SOLAS Persons Information	
Number of Person	0


## 3.2 Inland Settings



### 3.2.1 Vessel Data Setting

Inland related vessel data can be set in this submenu:

- ERI Ship Type - ERI classification code.
- ENI - European Number of Identification or European Vessel Identification Number
- Blue cones - The number of blue cones or blue flag status for the cargo (1, 2 or 3 blue cones, or blue flag).
- Load Status - "Loaded", "Unloaded", "Unknown"
- Quality of Speed, Course, Heading - will be shown as "High" when the target vessel is using an approved sensor to generate this data, or Low if the data is derived from internal GNSS only.
- Number of Tugboats - The number of assisting tugboats (from 0 to 6 or unknown)
- Air Draught - The air draught of the vessel. (vessel's highest point to waterline)



### 3.2.2 Number of Person


This submenu provides Number of Person (RFM55) setting:

The number of crew (0 to 254 or unknown), passengers (0 to 8190 or unknown) and other shipboard personnel (0 to 254 or unknown).




### 3.2.3 Blue Sign Setting

Blue Sign information helps you recognize the approaching vessels in your inland waterway area. A “blue sign” switch may optionally be connected to the AIS transceiver during installation. This setting enables or disables the blue sign switch on the Junction Box.



### 3.2.4 Report Rate Setting

Set M6's report rate. Selectable report rates are Auto/ 30 SEC./ 15 SEC./ 10 SEC. etc.



## 4 DOCUMENT REVISIONS

Date	Rev/Issue	Changes
2024-02-21	1	Initial issue
2024-04-18	2	P9, P54, P57, P60
2024-04-30	3	Graphics update
2024-09-11	4	UK Declaration of Conformity added.
2024-09-13	5	Minor typo corrections.

**NOTE:**

**NOTE:**

**NetWave Systems B.V.**

Blauw-roodlaan 100,

2718 SJ Zoetermeer

The Netherlands

Phone: +31 (0)881181500

Email: [info@seasofsolutions.com](mailto:info@seasofsolutions.com)

[www.seasofsolutions.com](http://www.seasofsolutions.com)